

8/31/10 - newest

Pg. 1 of




















Deluxe Kitchen / Utility Cart (R)

Assembly Instructions

Model 80690 - WHITE
Model 80696 - BLACK

HARDWARE

- | | |
|---|---|
| A 
M6 x 35mm x10 | J 
2" Stopper Caster
x2 |
| B 
M4 x 16mm x4 | K 
Wood Dowel
M7.8 x 30mm x2 |
| C 
M3.5 x 15mm x4 | L 
Metal Handle
x3 |
| D 
M4 x 30mm x12 | M 
Magnet
x2 |
| E 
5/32 x 22mm x6 | N 
2" Caster
x2 |
| F 
M4 x1 | P 
Wood Button
M13.5 x10 |
| G 
G-142 x4 | R 
Wood Screw
M4 x 25mm x4 |
| H 
L-115 x4 | S 
Drawer Front Block
Left & Right x2 |



IMPORTANT! DO NOT TIGHTEN SCREWS OR BOLTS UNTIL COMPLETELY ASSEMBLED!!

Customer Service 0607 - 652 7321




Deluxe Kitchen / Utility Cart (R)

Assembly Instructions


Model 80690 - WHITE

Model 80696 - BLACK



IMPORTANT! DO NOT TIGHTEN SCREWS OR BOLTS UNTIL COMPLETELY ASSEMBLED!!

Customer Service 0607 - 652 7321



IMPORTANT! DO NOT TIGHTEN SCREWS OR BOLTS UNTIL COMPLETELY ASSEMBLED!!

Customer Service 0607 - 652 7321